


TURBO EDGE 3-PART ADJUSTABI E SYPHON


IMPORTANT NOTES


Before installation flush supply pipes and ensure cistern is clean and free from debris.


No sealing compound, paste, flux or solvent to be used in contact with plastic or rubber surfaces to avoid damage. Rubber washers will provide adequate seal. PTFE tape may be used on threads. No chemical block/additive to be used in this cistern.


Do not over-tighten plastic fasteners. Hand tight + ¼ turn should provide an adequate seal (8Nm recommended).












FLUSH VOLUME	CONFIGURATION
MIN.	Only 'A' OPEN
LOW	Only 'B' OPEN
HIGH	Only 'C' OPEN
MAX.	All positions CLOSED

© 2025 TD_SISLF372602_15125 Iss H

Thomas Dudley 295 Birmingham New Road Dudley, West Midlands United Kingdom DY1 45J

- t +44 (0)121 557 5411
- **f** +44 (0)121 557 5345
- e info@thomasdudley.co.uk
- **w** www.thomasdudley.co.uk/plumbing



Final Installation Checklist

- Check moving components are not obstructed and move freely.
- Ensure lever connection is not in tension and allows syphon piston to fully return when at rest.
- Check connections are secure and fixed correctly.
- ~ Connect and turn on water supply.
- Check installation for leaks.
- Check water level aligns to that marked on cistern and is as close as adjustment allows to water level marked on syphon snap pin.
- Hold the valve open (float down) to check overflow operation is sufficient.
- Installer to ensure cistern complies with UK water regulations.
- Visit thomasdudley.co.uk/ plumbing for service & maintenance information.

