



Warning

18kg heavy product. It is recommended that at least two people carry out the installation to prevent personal injury or any damage to the urinal.

Important

Please read these instructions carefully before installation.

Disclaimer

1. The specifications of this product can change without notice as a result of continual product development.
2. These instructions are intended to be a general guide only as specific conditions vary from installation to installation.
3. The images in these instructions are for illustrative purposes only and may vary slightly from the actual product as a result of continual product development.
4. Check the product for defects or damage prior to fitting. Fitting the product is an acceptance that the product is free from defects and Thomas Dudley Limited cannot retrospectively accept responsibility for any defects subsequently discovered.

TYDE

295 Birmingham New Road
Dudley, West Midlands
United Kingdom
DY1 4SJ

A Thomas Dudley Business

t +44 (0)121 557 5411

f +44 (0)121 557 5345

e info@tyde.co.uk

w www.thomasdudley.co.uk/tyde



**Component Checklist**

1. Urinal
2. 3 x M10 threaded fixing studs
3. 3 x M10 lock nuts
4. 3 x M10 washers
5. Paper drilling template
6. Instruction leaflet

Equipment Checklist: Not Supplied

1. Drill, masonry bits and hole saw (optional) suitable to create required holes.
2. Adjustable Spanner
3. Spirit level
4. Pencil

Unpacking

1. Unpack the urinal and rest on a soft grit free surface to avoid scratches or other damage to the surface finish.
2. Check for any defects.

Urinal Preparation

1. Fit the desired water inlet spreader and piping that is long enough to go through the wall with enough spare to allow connection to the incoming water supply. Ensure that the pipe protrudes perpendicular to the rear face of the urinal.
2. Measure the distance from the centre of the bottom threaded fixing hole up to the centreline of the perpendicular section of the pipe. Mark this position on the paper drilling template.
3. Fit a Ø45mm or Ø 50mm urinal waste with a 90° elbow that if required reduces the outlet to 32mm or 1¼"
4. Measure the distance from the centre of the bottom threaded fixing hole up to the centre of the elbow outlet. Mark this position on the paper drilling template.
5. Connect a length of 32mm or 1¼" waste pipe to the elbow ensuring that it is long enough to pass through the wall with enough spare to allow easy connection to the outgoing waste pipework.
6. Hand tighten the three off M10 threaded fixing studs into the threaded inserts on the back of the urinal. If the supplied rods are not long enough to pass through the wall it will be necessary to cut lengths of standard M10 all-thread down to the correct size.

Wall Preparation

1. Ensure that the wall surface where the urinal is to be mounted is vertical, flat and free from protrusions and debris.
2. Ensure that the wall to which the urinal is fitted is structurally sound and capable of supporting the 18kg weight of the urinal.
3. Affix the paper drilling template to the wall at a height in accordance with the local recommended standards using masking tape, ensuring that it is level and crease free.
4. Using a pencil, mark the hole centres for the 3 off mounting positions, water inlet pipe and the waste pipe.



5. Remove the template and drill holes through the wall suitable to accept the following items:
 - a) 3 x M10 threaded fixing studs
 - b) 1 x inlet pipe
 - c) 1 x 32mm or 1¼" waste pipe
6. Rebate the water inlet and waste pipe holes if required to clear any fittings that protrude from the rear of the urinal.
7. Remove all debris from the holes.

Fixing the Urinal

Warning: The urinal weighs 18kg and should only be fitted using recognised safe lifting procedures.

Note: Fitting the urinal requires two people: one to lift and hold the urinal into position while the other secures it.

1. Lift the urinal and slide into position taking care not to damage either the pipe-work or the fixing studs.
2. From the other side of the wall secure the urinal into position using M10 washers and locknuts. Ensure that there is enough thread to fully engage the locknut.
3. Fit a suitable 32mm or 1¼" deep seal trap to the waste outlet.
4. Flush the incoming water supply pipes to remove any debris and trapped air.
5. Connect the pipe-work up to urinal to the incoming supply and waste as required.

Commissioning for Use

1. Fully open the water isolation tap and check the system for leaks.

Maintenance

1. It is not recommended that proprietary products be used for cleaning as the vast range of different chemical composition makes it impractical to test individually with the urinal.
2. Do not use scouring pads, abrasive cleaners, or sharp instruments.
3. In hard water areas lime scale removers can be used to remove lime scale deposits
4. Clean regularly using warm soapy water.
5. Matt Finish Urinals: Deeper cuts can be removed with 1200 grade wet and dry paper.
6. Gloss Finish Urinals: Light scratches and abrasions can be removed by rubbing with a soft cloth and liquid cutting compound.